

User Guide



Model - SC510N2-L HDMI



1. Introduction

SC510N2 SDI is a high-quality, high-performance capture device. It supports up to 4 channels of video inputs with SDI connectors.

2. Specification

	00540 NO 1 115141	
Model	SC510 N2-L HDMI	
Max. FPS	120/100fps @ 1920x1080p	
Dimension	140 × 64.41 (mm)	
Interface	PCIe x4	
Video Input	2 × HDMI	
Display Video Format	YV12,NV12,YUY2,RGB24,RGB32	
	1920×1080p@60/50fps	
	1920×1080p@30/25/24fps	
	1920×1080i@60/50fps	
	1280×720p@60/50fps	
	1280×1024p@60fps	
Display	1280×960p@60fps	
Video	1024×768p@60fps	
Resolution	800×600p@60fps	
	720×576p@50fps	
	720×576i@50fps	
	720×480p@60fps	
	720×480i@60fps	
	640×480p@60fps	
	1920×1080p@60/50fps	
	1920×1080p@30/25/24fps	
	1920×1080i@60/50fps	
	1280×720p@60/50fps	
	1280×1024p@60fps	
Recording	1280×960p@60fps	
Video	1024×768p@60fps	
Resolution	800×600p@60fps	
	720×576p@50fps	
	720×576i@50fps	
	720×480p@60fps	
	720×480i@60fps	



Audio Input	2 × embedded HDMI	
Audio Format	Stereo / 16-bit / 32000-48000Hz	
WatchDog	Yes	
SDK	VC++ / .NET / VB / V4L2	
System Requirement		
	Windows XP / Vista / Windows 7,8,10	
OS Support	Linux 2.6.14 or Higher	
	(32-bit and 64-bit)	

3 Packing List

Item	Amount
SC510 N2 HDMI Capture Card	1 (piece)
Watchdog cable	1 (piece)
USB stick or CD with driver	0 (piece)

4. Hardware Installation

Before You proceed

Please note below precautions before any install/uninstall operations:

- ✓ ALWAYS turn off the system before hardware installation/un-installation.
- ✓ ALWAYS unplug the power cord from the wall outlet/socket before hardware installation/uninstallation.
- ✓ ALWAYS touch a safely grounded object or metal object before touching the device.
- DO NOT touch any devices before the system is fully off.
- DO NOT touch any electrical and semiconductor components on the device, especially ICs on board.

4.1 Card and Driver Installation

- Step 1: Turn off the system and unplug power cord from wall outlet/socket.
- Step 2: Remove the computer system case cover.
- Step 3: Plug capture device into an available PCIe slot on motherboard.
- Step 4: After hardware installation is completed, then install the driver.

DRIVER can be downloaded from (vMix & DirectShow)

http://www.yuan.com.tw/en/market/software/vmixdriver/vmixdriver.htm



4.2 Signal Source Connection Diagram

4.3 Watchdog cable Installation (optional)

Watchdog function is to reset the PC automatically when the system is crashed on an unknown error.